



Bulk Filter & Verometer Filter Replacements



Forward Purge System

- Refer to Separate System Forward Purge Instructions



Filter Kits





Bulk Filter Maintenance





Prepare Bulk Kit By Pushing Centers Out





Lubricate O-Ring with Light Grease





Remove Filter Bowl With 1" Socket Wrench





Remove Filter Bowl With 1" Socket Wrench





Remove Filter Bowl With 1" Socket Wrench





Carefully Remove Bowl...A Small Amount of Odorant will Remain in the Bowl.





Place a Glove Over the Top of The Bowl to Prevent Smell/Spillage





Bowl Covered





Spray Old Filter Elements with Masking Agent





Remove Lock Nut & Retainer





Remove Filter Element Assembly





Element Removed





Dispose of Old Filter Elements and O-ring in Air Tight Container





Dispose of Old Filter Elements and O-ring in Air Tight Container





Prepare Kit Components





Assemble 12 Filter Rings on the Reusable S.S. Spool















Lubricate and Install New O-Ring In Filter Cap





Install the Filter Spool Assembly on the Filter Support Rod





Install the Retainer and Nut





Lubricate The Filter Bowl Threads with Light Lubricant





Install The Filter Bowl to The Filter Cap Hand Tight





Finish Tightening the Bowl with Your 1" Socket used in Removal.






Verometer Filter Maintenance



Prepare the Kit Components







Used a 3/8" Allen Wrench to Remove The Verometer Filter from the Bottom of The Verometer





CAUTION There Will Typically Be a Small Amount of Odorant Which Will Need to be Soaked up In a Paper Towel when Removing





Verometer Filter Assembly Removed






Carefully Remove O-Rings with an O-Ring Pick





Both O-Rings Shown Removed





Remove the Filter Element





Lubricate & Install O-Rings





Press Filter Into The End of Body





Reinstall The Assembly





Used a 3/8" Allen Wrench to Tighten The Verometer Filter in the Bottom of The Verometer Assy.

